



INTERNATIONAL ATOMIC ENERGY AGENCY
UNITED NATIONS EDUCATIONAL, SCIENTIFIC AND CULTURAL ORGANIZATION
INTERNATIONAL CENTRE FOR THEORETICAL PHYSICS
I.C.T.P., P.O. BOX 586, 34100 TRIESTE, ITALY, CABLE: CENTRATOM TRIESTE



H4.SMR/452-53

**ADRIATICO CONFERENCE ON
FOURIER OPTICS AND
HOLOGRAPHY**

OPTICAL CORRELATION:

APPLICATIONS VIEWGRAPHS

Prof. F. Docchio
Università degli Studi
Mompiano, Brescia Italy

OPTICAL CORRELATION: PRINCIPLES, TECHNIQUES AND APPLICATIONS

Franco Docchio
Dipartimento di Automazione Industriale
Universita' degli Studi
Via D. Valotti, 9
I-25060 MOMPIANO BS
Italy

OPTICAL CORRELATION

N.

OPTICAL CORRELATION: PRINCIPLES, TECHNIQUES AND APPLICATIONS


SUMMARY

- **PRINCIPLES OF OPTICAL CORRELATION**
 - Basic Mathematical formalism
- **DEVICES FOR OPTICAL CORRELATION**
 - Sources
 - Modulators
- **TECHNIQUES**
- **APPLICATIONS**

N.

OPTICAL CORRELATION

FREQUENCY PLANE CORRELATOR FPC



- at P2: $G(u,v) H(u,v)$
- antitransforming leads to correlation g^*h
- If $H(u,v)$ is the antitransform of pattern to be detected, then it is a Matched Spatial Filter
- Adaptive filtering, MFS synthesis with SLM's

N.

OPTICAL CORRELATION

SPATIAL MODULATORS FOR OPTICAL CORRELATION

• AMPLITUDE ONLY

- Apertures/masks
- Liquid Crystals TV's (LCTV's)

• AMPLITUDE AND PHASE

- Computer-generated holograms (CGH's)
- Spatial light modulators (Light valves)

• PHASE-ONLY MODULATORS

- Etched quartz plates
- Spatial light modulators

• TIME-SPACE CONVERSION

- Acousto-optical modulators (AOM's)

N.

OPTICAL CORRELATION

EXAMPLE OF SLM FOR OPTICAL CORRELATION




Figure 4.3 The Hughes liquid crystal light valve. (Reproduced by kind permission of Hughes Aircraft Company.)

N.

OPTICAL CORRELATION

OPTICALLY ADDRESSED SPATIAL LIGHT MODULATORS

SLM	Size	Mode of Operation	Sensitivity	Frame Time (ms)	Resolution (lp/mm)	Contrast Ratio	Optical Flatness	References
PROM	25 mm diam.	Reflection	5 $\mu\text{J}/\text{cm}^2$	33	6	10 ³ :1	$\lambda/10$ (r.m.s.)	[58]
Priz	18 mm diam.	Transmission	5 $\mu\text{J}/\text{cm}^2$	100	10			[60]
LCLV	(2 inch) ²	Reflection	8 mW/cm ²	80	25 [†]	100:1	< 3 $\lambda/4$ (pk-to-pk)	[54, 77] ^{††}
BSO LCLV	(15 mm) ²	Reflection	380 $\mu\text{W}/\text{cm}^2$	165	31	21:1	λ	[68] ^{††}
α -Si LCLV	(1.5 inch) ²	Reflection	20 $\mu\text{W}/\text{cm}^2$	50	35			[70]
Microchannel SLM ($\times 1699$)	16 mm diam.	Reflection	30 nJ/cm ²	150	10	> 10 ³ :1		[89]
α -Se ruticon	1.5 inch diam.	Reflection	1 $\mu\text{J}/\text{cm}^2$	8	14	22:1		[85]
Phototitius (α -Se/DKDP)	~ (2 cm) ²	Reflection	1 $\mu\text{J}/\text{cm}^2$	1	20	10:1		[82]
Ferpic (CdS/PLZT)	7.5 mm diam.	Reflection	20 $\mu\text{J}/\text{cm}^2$	0.1	20	4:1		[83]
Si LCLV p. diode	43 mm diam.	Reflection	40 $\mu\text{W}/\text{cm}^2$	25	12	20:1	4 λ	[64]

[†]Measured over circle of 16 mm diameter in centre of device.

^{††}In these devices, the low frame time and high resolution can be obtained simultaneously at the write sensitivity quoted.

N.

OPTICAL CORRELATION

ELECTRICALLY ADDRESSED SPATIAL LIGHT MODULATORS

SLM	Size	Resolution† (lp/mm)	Frame Time	Contrast Ratio	Optical Flatness	References
LIGHT-MOD						
256-03	(20 mm) ²	256 × 256	1 s (10 ms) ^{††}	10 ³ :1	λ/2	
128-03	(10 mm) ²	128 × 128	250 ms (2 ms) ^{††}		λ/2	[90]
48-05	(8.5 mm) ²	48 × 48	33 ms (700 μs) ^{††}		λ/2	
DMD	(6.4 mm) ²	(9.8)	16 ms	30:1		[97]
CLV	(20 mm) ²	800 × 500	33 ms	10 ³ :1		[101]
e-beam DKDP (Titus)	(50-75 mm) ²	(20)	33 ms	10 ³ -10 ³ :1	< λ/4	[100]
e-beam thermoplastic (Lumatron)	(1.5 inch) ²	(70)	1 s			[103]


†Or number of pixels.

††Frame rates for line-parallel address.

OPTICAL CORRELATION

N.

REAL-TIME JOINT CORRELATOR BASED ON LCTV SLM'S



Recorded image mux-ed with stored
image and joint-correlated in F-plane

N.

OPTICAL CORRELATION


MATERIALS FOR HOLOGRAM RECORDING

- PHOTOGRAPHIC EMULSIONS
- DICHROMATED GELATINS
- THERMOPLASTICS
- PHOTOREFRACTIVE MATERIALS
- PHOTOPOLYMERS
- PHOTORESISTORS

N.

OPTICAL CORRELATION

PRINCIPLE OF PHASE MODULATION IN PHOTOREFRACTIVE MATERIALS



N.

OPTICAL CORRELATION

HOLOGRAPHIC RECORDING MATERIALS FOR OPTICAL CORRELATION

Recording Material	Sensitivity ($\mu\text{J}/\text{cm}^2$)	Wavelength Range (Recording)	Thickness (μ)	Resolution (10^3 lp/mm)	Speed (ms)	Diffraction Efficiency (%)	Amplitude (A) or Phase (P) Modulation
Silver halide emulsion	10	blue to 750 nm	6-17	≤ 5	100	6	A
Dichromated gelatin	10^5	UV to 520 nm	1-13	> 5		80	P
Thermoplastics	100	blue to 1.15 μm	0.2-10	0.05-2.5 (peak)	250	32	P
Photorefractive BSO	300	blue	0.4-2 mm	0.03-1	20 (at 10 mW/cm ²)	0.3 (zero field) 25 (9 kV/cm)	P
Photochromics	10^5	488, 514, 633	variable	> 3	very fast	1	A
Photopolymer [116] DMP-128	10^4	visible	1-30	≤ 1.6	~ min	90	P
Photoresistors	10^5	UV to 500 nm	≤ 4	> 1	100	10	P

N. OPTICAL CORRELATION

OPTICAL CORRELATION: SUMMARY OF APPLICATIONS 1

● MILITARY

- Missile guidance
- Vehicle guidance
- Radar signal processing
- Synthetic Aperture Radar
- Aerial Photometry

● ASTRONOMY/AERIAL

PHOTOGRAPHY/PHOTOMETRY

- Astrophotography (speckle Masking)
- Aerial photography
- Aerial Photometry
- Geographical Monitoring

● SPACE EXPLORATION

- On-board vision systems

N.

OPTICAL CORRELATION

OPTICAL CORRELATION: SUMMARY OF APPLICATIONS

2

● SIGNAL PROCESSING

- Multichannel spectrum Analysis (real time)
- Optical radio (hopping signal detection)
- Heterodyne transform
- Variable matched filtering
- Adaptive filtering

● INDUSTRIAL APPLICATIONS

- Image processing and restoration
- Image filtering/contrast enhancement
- Pattern recognition: matching objects to templates
- Robot guidance
- Quality control

● BIOMEDICAL APPLICATIONS

- Image restoration and pattern recognition (CAT, NMR, ECG, OFA)

N.

OPTICAL CORRELATION

INDUSTRIAL APPLICATIONS OF OPTICAL CORRELATION

- Quality control of manufacts
- Recognition of objects in production lines
- Robot guidance
- In-production monitoring of polymer growth/particle sizing

N.

OPTICAL CORRELATION


GENERAL PROBLEMS RELATED TO INDUSTRIAL APPLICATIONS OF OPTICAL CORRELATION

- Scale and rotation invariance
- Size of the target
- Throughput
- Multiple images
- 3-D monitoring
- Real-time operation
- Simple architectures


N.

OPTICAL CORRELATION


GENERAL PROBLEMS RELATED TO INDUSTRIAL APPLICATIONS OF OPTICAL CORRELATION




a) simple



b) scale and rotation



c) background



d) multiple images

N.

OPTICAL CORRELATION

WHY OPTICAL?

- Frame grabbers/PC computer performances

- 512x512 typical camera dimensions
- Real time grabber acquisition (30 frames/s)
- Arithmetic processing w/o array proc.: minutes!
- Arithmetic processing w/ array proc.: seconds!


WHY FOURIER?

- Insensitivity to displacement
- Multiplication easier than correlation

N.

OPTICAL CORRELATION


THE PROGRAMMING VIEW OF ROBOTICS



N.

OPTICAL CORRELATION

SENSORS AND MANIPULATORS IN ROBOTICS



N.

OPTICAL CORRELATION

SCALE- AND ROTATION INVARIANT TECHNIQUES FOR OPTICAL CORRELATION


- Scale invariance
 - Mellin Transforms
 - Logarithmic radial harmonic filters
 - Anamorphic correlation
- Rotation invariance
 - Circular harmonic filtering
 - Optimum feature extraction

N.

OPTICAL CORRELATION

DETECTION OF OBJECTS IN A BACKGROUND USING FOURIER FILTERING TECHNIQUES

Object plane



Fourier plane






Image plane



N.


OPTICAL CORRELATION

ADDITIVITY OF FOURIER-FILTERED IMAGES



Non-filtered image

Non-additive



Filtered image

Additive

N.

OPTICAL CORRELATION

Made in Italy


EXAMPLES OF INDUSTRIAL APPLICATIONS OF OPTICAL CORRELATION AND FOURIER FILTERING

- Real time spatial filtering for dark-field contrast enhancement
 - Brescia (Docchio et al., 1989)
- Pattern recognition with computer-generated binary holograms
 - Nerviano (Vanotti et al., 1989)
- Optical particle sizing with the Chahine inversion scheme
 - Milano (Bassini et al., 1989)
- Coherent Fourier image processing
 - Trieste (Sirotti and Rizzato, 1989)


N.

OPTICAL CORRELATION


LAYOUT OF A FOURIER FILTERING SYSTEM FOR TRANSMISSION/REFLECTION CONTRAST ENHANCEMENT (Docchio et al., 1989)



DARK FIELD CONTRAST ENHANCEMENT WITH FOURIER FILTERING: A METALLIC WIRE (Docchio et al., 1989)




Unfiltered



Filtered




I vs x




2-D

**DARK-FIELD CONTRAST ENHANCEMENT:
DETECTION OF SCRATCHES ON GLASS SURFACES**
(Docchio et al., 1989)

**EDGE ENHANCED PROFILES OF MECHANICAL
TOOLS WITH DFCE**
(Dacchio et al., 1989)






a)



b)

**DETECTION OF A SCRATCH ON A RULED TRANSPARENT
SURFACE (Dacchio et al., 1989)**



Scratch at 15° with respect to rules

OPTICAL PARTICLE SIZE USING THE CHAINE INVERSION TECHNIQUE (Bassini et al., 1989)

- Dispersion of granules analysed using spherical wave
- Fraunhofer approximation for diffracted field
- Ring-shaped detector geometry with centered hole
- Scale is changed by cell translation

N.

OPTICAL CORRELATION


PATTERN RECOGNITION WITH COMPUTER-GENERATED SPOFS (Yip et al., 1989)

- CGH's based on Psaltis's technique
- MOLSM as spatial modulator
- Applications to industrial pattern recognition in robotics

N.

OPTICAL CORRELATION

COMPARISON BETWEEN MATCHED, PHASE-ONLY, AND BINARY PHASE-ONLY FILTERS



OPTICAL CORRELATION

N.

BIOMEDICAL APPLICATIONS OF OPTICAL CORRELATION

potential

- Automated image processing
- Recognition of patterns in relation to pathology/ageing
- Studies on the morphogenesis of biological structures through the analysis of their fractal properties

N.

OPTICAL CORRELATION

PROBLEMS RELATED TO BIOMEDICAL APPLICATIONS OF OPTICAL CORRELATION

- Biological tissues exhibit highly irregular, non-periodic structures
- Fractal geometries often exhibited
- Diagnosis often presents less stringent requirements of real-time operation
- Fewer scale- and orientation problems, but more problems related to templates
→ matched filtering difficult

N.

OPTICAL CORRELATION


EXAMPLES OF BIOMEDICAL AREAS FOR THE APPLICATION OF OPTICAL CORRELATION

- Cardiology
 - Identification of stenotic vessels from angiograms
 - Analysis of ECG maps
- ORL
 - Studies of lung morphogenesis and structural/physiological evolution
- Ophthalmology
 - Analysis of fundus photographs and fluorescein angiograms in relation to the diagnosis of diabetic retinopathy/senile macular degeneration


N.

OPTICAL CORRELATION

EXAMPLES OF BIOMEDICAL IMAGING: FLUORESCCEIN ANGIOGRAPHY



a) Photograph



b) Digitized vessel profile for the
study of fractal patterns

N.

OPTICAL CORRELATION

FUTURE OF OPTICAL CORRELATION /FILTERING APPLICATIONS (but I may be wrong!)

- Industrial applications of optical correlation will have to consider the tremendous increase in the performances of digital image processors
- Biomedical applications of optical correlation still need full exploitation. Template matching in the Fourier plane may help diagnosis. Potential for follow-ups.

N.

OPTICAL CORRELATION

