



2063-12

ICTP/FANAS Conference on trends in Nanotribology

19 - 24 October 2009

The extreme and unusual nanotribological properties of carbon

Robert Carpick University of Pennsylvania Philadelphia USA

Strada Costiera II, 34151 Trieste, Italy - Tel.+39 040 2240 III; Fax +39 040 224 163 - sci_info@ictp.it

The extreme and unusual tribological properties of carbon

Robert W. Carpick University of Pennsylvania Philadelphia, Pennsylvania, USA



Dept. of Mechanical Engineering and Applied Mechanics <u>http://www.me.upenn.edu/~carpick</u>

> Penn Director, The Nanotechnology Institute http://www.nanotechinstitute.org

Macroscale friction and wear: environmental passivation and switching behavior
Atomic-scale friction of graphene: size (# of layers) matters

2009 R.W. Carpick

A special promotional message

The Nanoprobe Network: <u>http://nanoprobenetwork.org</u> A free resource for scanning probe microscopists

-<u>Forums</u> for asking and answering SPM questions, including live chats with experts once a month -<u>Probe-pedia</u>: The user-generated encyclopedia of SPM

-Blogs by scientists in academia and industry

-Shared software, images, video files

-Coming soon: Job listings

© 2009 R.W. Carpick

Acknowledgements:

A.R. Konicek, Dr. Q. Li U. Pennsylvania

Prof. K. Turner, J. Liu, Prof. P.U.P.A. Gilbert, D.S. Grierson U. Wisconsin-Madison

Prof. W.G. Sawyer, J. Keith U. Florida

Dr. A.V. Sumant, Dr. O Auciello Argonne National Laboratories


Dr. J. Carlisle, Dr. N. Moldovan Advanced Diamond Technologies

Prof. J. Hone, Dr. C. Lee Columbia University


Dr. A. Schöll, Dr. A. Doran Advanced Light Source, Lawrence Berkeley National Laboratories

Support: Air Force Office of Scientific Research, National Science Foundation, Synchrotron Radiation Center (UW-Madison), Advanced Light Source (Lawrence Berkeley National Laboratory), Department of Energy (Argonne – Center for Nanoscale Materials)`


© 2009 R.W. Carpick





Tribological Applications of Diamond





Ultrananocrystalline diamond (UNCD)		
Growth \longrightarrow	Large-area chemical vapor deposition	Ar-1%CH4
Roughness \rightarrow	Small grain size (2-5 nm), low roughness (<8 nm RMS)	1.5 pm GB
Bonding	Diamond nanograins, with sp ² / sp ³ grain boundaries	
Modulus	Young's modulus ~960 GPa (single crystal diamond: 1050 GPa)	9:5 nm 1 nm
Hardness —→	Hardness ~90 GPa (single crystal diamond: 100 GPa)	TEM image of UNCD nanograins Source: Argonne
© 2009 R.W. Carpick	Graphite Sp ² Diamond Sp ³	National Labs

















































Summary of UNCD tribology

- Self-mated UNCD interfaces under rather dry conditions have impressively good performance
 - extremely low friction (down to 0.005 at <1% RH)
- The formation of a crystalline graphite layer is NOT the mechanism of low friction under any conditions tested
 - Some amorphous carbon is found
- Oxidation occurs, particularly under more severe conditions; chemical passivation (by -H, or -OH) is the key
 - there is a dynamic competition between bond breaking (leading to bonding across the interface and wear) and bond passivation by dissociative adsorption (which is clearly feasible from energetics)
 - Leads to rapid switching between low & high friction with a small change in humidity: runaway behavior

© 2009 R.W. Carpick