INTRODUCTION TO LASER

IMRANA ASHRAF ZAHID

05/02/2015

Layout

- Fundamentals of Laser
 - -Introduction
 - **–Properties of Laser Light**
 - **–Basic Components of Laser**
 - **–Laser operation**
 - -Types of Lasers
 - -Laser Applications

Introduction

LASER

Light Amplification by Stimulated Emission of Radiation.

- An optical source that emits photons in a coherent beam.
- In analogy with optical lasers, a device which produces any particles or electromagnetic radiations in a coherent state is called "Laser", e.g., Atom Laser.
- In most cases "laser" refers to a source of coherent photons i.e., light or other electromagnetic radiations. It is not limited to photons in the visible spectrum. There are x-rays, infrared, UV lasers etc.

Properties of Laser Light

- The light emitted from a laser is *monochromatic* -it is of one color/wavelength. In contrast- ordinary white light is a combination of many colors (or wavelengths) of light.
- Lasers emit light that is highly *directional* laser light is emitted as a relatively narrow beam in a specific direction. Ordinary light - such as from a light bulb - is emitted in many directions away from the source.
- The light from a laser is said to be *coherent* wavelengths of the laser light are in phase in space and time. Ordinary light can be a mixture of many wavelengths.

Ordinary Light vs. Laser Light



Laser Light

Ordinary Light

Basic Components of Laser

Laser system consists of three important parts.

- 1. Active medium or laser medium
- 2. An energy source (referred to as the pump or pump source)
- 3. An optical resonator consisting of a mirror or system of mirrors



05/02/2015

Basic Components of Laser

Active Medium

Major determining factor of the wavelength of operation and other properties of laser.

- Hundreds of different gain media in which laser operation has been achieved.
- The gain medium may be solid crystals such as ruby or Nd:YAG, liquid dyes, gases like CO₂ or Helium-Neon, and semiconductors such as GaAs.

Pumping Mechanism

- The pump source is the part that provides energy to produce a population inversion.
- Pump sources include electrical discharges, flash lamps, light from another laser, chemical reactions.
- The type of pump source used principally depends on the gain medium.
 Optical Resonator
 - Its simplest form is two parallel mirrors placed around the gain medium.
- Light from the medium produced by the spontaneous emission is reflected by the mirrors back into the medium where it may be amplified by stimulated emission.
- One of the mirrors reflects essentially 100% of the laser light while the other reflects less than 100% of the laser light and transmits the remainder.

Basic Principles of Light Emission and Absorption 1

In 1916, Einstein considered various transition rates between atomic states (say, 1 and 2) involving light of intensity, *I*.

Absorption:

Absorption is the process by which the energy of the photon is taken up by another entity, e.g., by an atom whose valence electrons make transition between two electronic energy levels. The photon is destroyed in the process.

Rate of Stimulated Absorption = $B N_1 I$

B Einstein's Coefficient for Stimulated Absorption

N₁ Population in the Ground State



05/02/2015

Basic Principles of Light Emission and Absorption 2

<u>Stimulated Emission:</u>

A process by which, when perturbed by a photon, matter may lose energy resulting in the creation of another identical photon.

Rate of stimulated emission = $B N_2 I$

B Einstein's Coefficient for Stimulated Emission

N₂ Population in the Excited State

• Spontaneous Emission:

A process by which an atom, molecule in an excited state drops to a lower energy level.

Rate of spontaneous emission = *A N*₂ A Einstein's Coefficient for Spontaneous Emission





Threshold Condition



A laser action will be achieved if the beam increases in intensity during a round trip: that is, if $I_3 \ge I_0$

Usually, additional **losses** in intensity occur, such as absorption, scattering, and reflections. In general, the laser will lase if, in a round trip:

This is called achieving **Threshold**.

Laser Gain

Laser medium

$$I(0) \rightarrow \square \rightarrow I(L)$$

$$+ \square \rightarrow Z$$

$$0 \qquad L$$

Neglecting spontaneous emission:

 $\frac{dI}{dt} = c \frac{dI}{dz} \propto BN_2 I - BN_1 I \text{ [Stimulated emission minus absorption]} \\ \propto B[N_2 - N_1] I \\ I(z) = I(0) \exp\{\sigma[N_2 - N_1] z\} \text{Proportionality constant is the absorption/gain cross-section,} \\ \sigma$

There can be exponential gain or loss in intensity. Normally, $N_2 < N_1$, and there is loss (absorption). But if $N_2 > N_1$, there's gain, and we define the gain, *G*:

$$G = \exp\left\{\sigma \left[N_2 - N_1\right]L\right\}$$

If
$$N_2 > N_1$$
: $g \equiv [N_2 - N_1]\sigma$
If $N_2 < N_1$: $\alpha \equiv [N_1 - N_2]\sigma$

Population Inversion

In order to achieve G > 1, that is, stimulated emission must exceed absorption:

 $BN_2I > BN_1I$

Equivalently,

 $N_2 > N_1$

This condition is called *population inversion*. It does not occur naturally. It is inherently a non-equilibrium state.

In order to achieve inversion, we must pump the laser medium in some way and choose our medium correctly.

Population inversion is the necessary condition for laser action.

05/02/2015

Two-, Three-, and Four-Level Systems





College on Optics

Optical Resonators

- Cavities are essential components of the lasers. They provide the required feedback for laser oscillation.
- Cavities also act as resonators and frequency filters.
- Drastically reduce the number of modes that can oscillate with low loss.
- Practical resonator sizes range from micrometers to meters.

Closed vs. Open Cavities

- In closed cavities the cavity modes correspond to stationary electric field configurations.
- In lasers we use open cavities- to have much smaller number of modes.
- The electric field of a mode can be written as:

$$\mathbf{E}(\mathbf{r}, t) = E_0 \mathbf{u}(\mathbf{r}) \exp[(-t/2\tau_c) + j\omega t]$$

- Where Tc is called the -cavity photon decay time.
- Need to find stable solutions for u(r).

Plane-Parallel (Fabry-Perot) Resonator

 The resonant frequencies -the longitudinal modes of the cavity are

$$v = n\left(\frac{c}{2L}\right)$$
 $L = n(\lambda/2)$



- The cavity modes form standing waves-the amplitude is zero at the mirrors.
- The frequency difference between two consecutive longitudinal mode $\Delta v = \frac{c}{2L}$

These frequencies are called the -longitudinal modes.

Concentric Resonator

This resonator is made of two spherical mirrors of coincident centers.



All rays have the same path length. Resonant frequencies are the same as the plane parallel resonator of separation L.

05/02/2015

Confocal Resonator



the resonant frequencies cannot be obtained from geometrical optics, hence they are different from plane parallel resonator.

Generalized Spherical Resonator

 Resonators can also have cavity separation between concentric and confocal resonators.

- The mirrors can also be convex.
- For this case, we cannot find a complete loop with ray tracing.

A resonator is called **stable** if the rays tend to stay within the cavity. A resonator is **unstable** if the rays diverge after some bounces.



An unstable resonator.

Ring Resonator

- The optical path is arranged in a ring configuration. For resonant frequencies- the total phase shift after one round trip should be an integer multiple of 2π .
- Ring resonators can also be stable or unstable.
- Resonance frequencies are given by:

$$\mathbf{v} = \frac{nc}{L_p}$$

• Where Lp is the length of the perimeter of the ring.



Stable Resonators

- Multiple bounces between the cavity mirrors can also be considered as continuous propagation through periodic lenses.
- For stable propagation, the field should reproduce itself after one round trip.



We use ABCD matrix method to find the stability condition.

05/02/2015

Stability Condition

 To find the condition for stable oscillation within the cavity, we will use the ABCD matrices.



For one round-trip:

For *n* roundtrips:

Preparatory School to Winter College on Optics

 $\begin{vmatrix} r_n \\ r'_n \end{vmatrix} = \begin{vmatrix} A & B \\ C & D \end{vmatrix} \begin{vmatrix} r_0 \\ r'_n \end{vmatrix}$

 $\begin{vmatrix} r_1 \\ r'_1 \end{vmatrix} = \begin{vmatrix} A & B \\ C & D \end{vmatrix} \begin{vmatrix} r_0 \\ r'_0 \end{vmatrix}$

05/02/2015

Stability Condition

This condition holds even if the cavity contains other elements. If the resonator is to be stable, we require that, for any initial point (*r*₀, *r*'₀), output point (*r*_n, *r*'_n), does not diverge as *n* increases. This means that the matrix

$$\begin{vmatrix} A & B \end{vmatrix}^n$$

 $\begin{vmatrix} C & D \end{vmatrix}$

Must not diverge as n increases.

Sylvester's Theorem

Defining: $\cos \theta = (A + D)/2$

$$\begin{array}{c|c} A & B \\ C & D \end{array} \Big|^n = \frac{1}{\sin \theta} \left| \begin{array}{c} A \sin n\theta - \sin(n-1)\theta & B \sin n\theta \\ C \sin n\theta & D \sin n\theta - \sin(n-1)\theta \end{array} \right.$$

 $\sin n\theta = [\exp(jn\theta) + \exp(-jn\theta)]/2j$

If θ has an imaginary part- jn θ term becomes real and diverges with n.

Therefore, n'th power of the matrix does not diverge if θ is real.

The stability condition:

$$-1 < \left(\frac{A+D}{2}\right) < 1$$

05/02/2015

Generalized Spherical Resonator



$$\begin{vmatrix} A & B \\ C & D \end{vmatrix} = \begin{vmatrix} 1 & 0 \\ -2/R_1 & 1 \end{vmatrix} \begin{vmatrix} 1 & L \\ 0 & 1 \end{vmatrix} \begin{vmatrix} 1 & 0 \\ -2/R_2 & 1 \end{vmatrix} \begin{vmatrix} 1 & L \\ 0 & 1 \end{vmatrix}$$

$$\frac{A+D}{2} = 1 - \frac{2L}{R_1} - \frac{2L}{R_2} + \frac{2L^2}{R_1R_2} = 2\left[1 - \left(\frac{L}{R_1}\right)\right] \left[1 - \left(\frac{L}{R_2}\right)\right] - 1$$

by defining dimensionless g parameters: The stability co

$$g_1 = 1 - \left(\frac{L}{R_1}\right)$$
$$g_2 = 1 - \left(\frac{L}{R_2}\right)$$

The stability condition becomes:

$$0 < g_1 g_2 < 1$$

ABCD matrices for different optical elements



AD - BC = 1

Modes of Laser Resonator

The mathematical function that describes the Gaussian beam is a solution to the paraxial form of the Helmholtz equation. The solution, in the form of a Gaussian function, represents the complex amplitude of the beam's electric field.

Gaussian Mode

- Many lasers operating on fundamental Transverse mode, or TEM₀₀ mode of the laser resonator, emit beams with a Gaussian profile.
- The Gaussian beam is a radially symmetrical distribution whose electric field vitiations are given as

$$E = E_0 \left(-\frac{r^2}{\omega_0^2} \right)$$

r is defined as the distance from the center of the beam and w0 is the radius at which the amplitude is 1/e of its value on the axis.

Higher-order Modes

- If beam is not a pure Gaussian shape, the transveres modes of the beam may be analyzed as a superposition of Hermite-Gaussian or Laguerre-Gaussian beams.
- Other solutions to the paraxial form of the Helmholtz equation exist. Solving the equation in Cartesian coordinates leads to a family of solutions known as the Hermite–Gaussian modes, while solving the equation in cylindrical coordinates leads to the Laguerre–Gaussian modes.

Hermite-Gaussian Modes



Laguerre- Gaussian modes



Laser Beam Output

1

- Characteristics that affect laser performance are the power output and mode of emission - continuous wave, pulsed, Qswitched or Mode –locked lasers.
- **CW laser** emits a continuous beam of light as long as medium is excited.
- Pulsed laser- emit light only in pulses- from femtoseconds to second
- Q-switched laser-pulses from micro to nanosecond are produced
- Mode-Locked laser –pulses from pico (10⁻¹²s) to femtoseconds (10⁻¹⁵s) are produced

Laser: Q-switching

- Q-switching is a way of obtaining short from a few nano -seconds to few tens of nano -seconds powerful from a few megawatts to few tens of megawatts- pulses of laser.
- Q quality factor of laser resonator.
- High Q Low losses
- Low Q High losses
- The term Q-switching refers to an abrupt switching of the cavity Q from low value to a high value.

Laser: Mode-Locking

 Mode-locking - technique that allowed the generation of ultra- short optical pulse in the range of femtosecond.

Principle of Mode-Locking

- Mode-locking- achieved by locking together the phases of all oscillating axial laser modes having slightly different frequencies.
- Interference between these modes causes the laser light to be produced as a train of pulses.

Physical Properties of Laser

- Energy- the amount of work accomplished measured in joules
- 2. Power- Rate of energy expenditure measured in joules per second or Watts (1J/s =1 W)
- 3. Irradiance- power density- the power of the laser per unit area.
- Fluence energy density- amount of energy delivered per unit area - irradiance multiplied by the exposure time (j/cm²).

Types of Laser

Lasers are usually classified in terms of their active (lasing) medium. Major types are:

- Solid-state lasers
- Semiconductor Lasers
- Dye Lasers
- Gas Lasers
- Excimer Lasers





Types of Lasers

- Solid-state lasers have lasing material distributed in a solid material (such as ruby or neodymium: yttriumaluminum garnet "YAG"). Flash lamps are the most common power source. The Nd:YAG laser emits infrared light at 1.064 micrometers.
- Semiconductor lasers sometimes called diode lasers- are pn junctions. Current is the pump source.
 Applications: laser printers or CD players.
- Dye lasers use complex organic dyes, such as rhodamine 6G, in liquid solution or suspension as lasing media. They are tunable over a broad range of wavelengths.

05/02/2015

Types of Lasers

- Gas lasers are pumped by current. Helium-Neon lases in the visible and IR. Argon lases in the visible and UV. CO₂ lasers emit light in the far-infrared (10.6 micro m), and are used for cutting hard materials.
- Excimer Lasers different reactive gases (e.g chlorine, fluorine) are used with inert gases (e.g argon, xenon, and krypton). Mixture of these gases is excited- resulting in the release of a stimulated molecule- called dimer. Upon lasing this dimer produces ultraviolet lasers. The term Excimer comes from excited dimer

Applications of Laser

- Laser considered to be "a solution in search of a problem" in 1958. Now Laser has many applications
- Scientific Applications.
- Commercial Applications.
- Medical Applications.
- The properties like Coherence, mono-chromaticity, and ability to reach extremely high powers, allow for these specialized applications.

Scientific Applications

- Laser Spectroscopy: atmospheric physics pollution monitoring-cancer detection
- Optical metrology: optical distance measurement- optical temperature measurements etc.,
- Optical frequency metrology: for precise position measurements
- Laser induced breakdown spectroscopy: Solid materials can be analyzed
- Laser cooling: makes it possible to bring clouds of atoms or ions to extremely low temperatures
- Optical tweezers: used for trapping and manipulating small particles- such as bacteria or parts of living cells.
- Laser microscopes: provide images of, e.g., biological samples with very high resolution - often in three dimensions

Scientific Applications

Communications:

- Optical fiber communication: extensively used for long-distance optical data transmission-relies on laser light in optical glass fibers.
- Free-space optical communications: for inter-satellite communications- is based on higher-power lasers- generating collimated laser beams which propagate over large distances with small beam divergence.

Commercial Applications

- Cutting, welding, marking,
- Rangefinder / surveying,
- LIDAR / pollution monitoring,
- CD/DVD player,
- Laser printing,
- Laser engraving of printing plates,
- Laser pointers, holography, laser light displays
- Optical communications.



Medical Applications

- Cosmetic surgery:
- Dentistry:
- Dermatology:
- Eye surgery:
- Cardiology:
- Neurology:
- Urology:
- Optical Imaging:



Laser : Medical Applications

- Cosmetic surgery: removing tattoos, scars, stretch marks, wrinkles, birthmarks, and hairs.
- Dentistry: caries removal, tooth whitening, and oral surgery.
- Dermatology: Treatment of acne and skin cancer by PDT
- Eye surgery: Cataract and Glaucoma surgery

Laser : Medical Applications 2

- Cardiology: Angioplasty, vessel recanalization
- Neurology: To cut, ,vaporize and coagulate tissue with out mechanical contacts
- Urology: lithotripsy (removal of kidney stones)
- Laser scalpel: gynecology, urology, laparoscopy
- Optical Imaging: field of online monitoring and diagnostics

References

- LASERS: Peter W, Milonni and Joseph H. Eberly
- LASERS : Anthony E. Siegman
- LASER FUNDAMENTALS: William T. Silfvast

THANK YOU

05/02/2015